

The following additional instructions replace the information detailed in the main instruction booklet at the pages indicated in last column of the table below

<u>EN</u>	<u>FUNCTION</u>	<u>CHANGE</u>	<u>NEW INSTRUCTIONS</u>
	Descaling process can be interrupted even if already in progress	ADDED	Please press the ON/OFF main button
	Descaling alarm can be disabled	ADDED	Press the MENU button. Press the  button and select the "MACHINE MENU" option. Press the  button to access the menu. Press the  button and select the GENERAL menu. Select Descal Warning and choose ON or OFF. Confirm with OK. OFF: With this setting, the warning message is disabled. ON: With this setting, the warning message is active. The message is displayed when the machine needs to be descaled.
	Stand-by - Default value	60 minutes (before 30 min.)	Press the MENU button. Press the  button and select the "MACHINE MENU" option. Press the  button to enter the "GENERAL MENU". Press Stand-by settings, scroll down and choose OFF. Confirm with OK.
	Stand-by can be disabled	ADDED	STAND-BY SETTINGS: To set the time interval for the machine to go into stand-by mode after the last brewing. The default time value is «after 60 minutes». Once the set time has elapsed, the machine goes into stand-by mode. Press any button to turn the machine back on. After performing the function diagnostics and the warm-up phase, the machine is again ready for use. When this parameter is set to "OFF", the machine stays active.
	Self-learning "memo" function on beverages can be activated/disabled	ADDED	Press the MENU button Press the  button and select the "MACHINE MENU" option Press the  button and select the "GENERAL MENU". Press "Self-learning", scroll down and choose ON or OFF. Confirm with OK.
	Pre-grinding function can be activated/disabled	ADDED	Press the MENU button Press the  button and select the "MACHINE MENU" option. Press the  button to enter the "GENERAL MENU". Select PRE_GRINDING, scroll down and choose ON or OFF. Confirm with OK. IMPORTANT! Dont' change the coffee dose with pre-grinding set to ON on machines where this option is valid.

As seguintes instruções adicionais substituem as informações detalhadas no manual de instruções principal nas páginas indicadas na última coluna da tabela abaixo

PT	FUNÇÃO	ALTERAÇÃO	NOVAS INSTRUÇÕES
	O processo de descalcificação pode ser interrompido, mesmo que já esteja em curso	ADICIONADO	Pressione o interruptor ON/OFF principal
	O alarme de descalcificação pode ser desactivado	ADICIONADO	Pressione a tecla MENU Pressione a tecla  e seleccione a opção "MACHINE MENU". Pressione a tecla  para aceder ao menu. Pressione a tecla  e seleccione a opção menu GERAIS Seleccionar AVISO de descalcificação e escolher ON ou OFF. Confirmar com OK. OFF: Com esta definição, a mensagem de aviso é desactivada. ON: Com esta definição, a mensagem de aviso é activada. A mensagem é apresentada quando a máquina necessita de ser descalcificada.
	Stand-by - valor predefinido	60 minutos (antes 30 min.)	Pressione a tecla MENU Pressione a tecla  e seleccione a opção "MACHINE MENU". Pressione a tecla  para entrar no "GENERAL MENU". PROGRAM.STAND-BY Pressione Program. Stand-by, rolar para baixo e escolher OFF. Confirmar com OK
	O modo de stand-by pode ser desactivado	ADICIONADO	STAND-BY SETTINGS: Para definir o intervalo de tempo para a máquina entrar no modo de stand-by após a última distribuição. O valor de tempo predefinido é «após 60 minutos». Depois de decorrido o tempo definido, a máquina entra automaticamente no modo de stand-by. Pressione qualquer tecla para ligar novamente a máquina. Depois de realizar a função de diagnóstico e a fase de aquecimento, a máquina está novamente pronta para ser utilizada. Quando este parâmetro é definido para "OFF", a máquina permanece activa.
	A função de "memorização" de auto-aprendizagem das bebidas pode ser activada/desactivada.	ADICIONADO	Pressione a tecla MENU Pressione a tecla  e seleccione a opção "MACHINE MENU" Pressione a tecla  para entrar no "GENERAL MENU". Seleccionar AUTO-APRENDIZAGEM, rolar para baixo e escolher ON ou OFF. Confirmar com OK.
	A função pré-moagem pode ser activada/desactivada	ADICIONADO	Pressione a tecla MENU Pressione a tecla  e seleccione a opção "MACHINE MENU". Pressione a tecla  para entrar no "GENERAL MENU". Seleccionar PRE-MOAGEM, rolar para baixo e escolher ON ou OFF. Confirmar com OK. IMPORTANTE! Não altere a dose de café com a pré-moagem definida para ON em máquinas onde esta opção é válida.